



COMPUTER/VGA:

Desktop, laptop, or document camera connection.

HDMI:

Most laptops and all DVD players.

SPECIAL USB:

Used to connect touch screen features for Windows 8.1 enabled computers.
**NOT AN INTERNET PORT –
REQUIRES SPECIAL USB CABLE.**

AUDIO:

Audio from headphone jack on computer, laptop or MP3 players.